


Cyclonic Load:



The wind load is calculated by the amount of core holes filled, as well as the reinforcement used.

The system is basically reinforced concrete and will easily withstand cyclonic conditions, upon design by the engineer.

